

Checklist for approved assembly.

Figures in parentheses refers to the current item in installation instruction 815-9104-0-01

- The wall must be built to withstand the installation of doors.
Make sure the door is rated for mounting in the current wall type.
- Check the wall opening in relation to the required sizes of the door set. For frames prepared with electric strike, the wall opening may need to be modified. See separate installation instruction electric strike plate on our website.
- (1) If the wall opening exceeds the specified tolerances it should be adjusted without compromising to fire resistance, smoke control or sound reduction characteristics.
- (3) Frame with unmounted stone wool from the factory. The frame has been insulated with the supplied stone wool according to instruction 815-9106-0-01 before mounting the frame is made in the wall
- (4.1) Floor surface checked, it must be horizontal and free from dirt and unevenness.
- (4.2) The frame is centered in the wall opening. Ensure that the frame is positioned vertically and horizontally in correct position.
- (4.3) Do not tighten the jacking screws to hard as there is a risk that the frame may arch.
- (5) Gap between the frame and door leaf according to instructions.
- All jacking screws are aligned to the wall at lock- and hingeside .
- (9) Insulated between frame and wall with insulation according to instructions.
- (13) If the frame is equipped with adjustment screws at the bolt protection, these must be screwed towards the wall.
- (14) The door opens and closes properly and that the sealing strips are intact and free from damage. Lubricate the lock case and piston exterior with grease intended for the purpose. See Care and Maintenance Instructions (815-9100-0-01)
- (15) Caulking is performed according to given instructions.
- Any adjustments are made as instructed.
- Care and maintenance instructions (815-9100-0-01) are available.
- The presented characteristics of the door can only be met by using locks- and other fittings approved by Robust Ståldörrar AB.
See more information on our website. www.robust.se
- If alterations are made to the doorset, Robust Ståldörrar AB cannot ensure the declared performance and properties.
- Installation of any other fitting on site must be carried out in accordance with professionalism and according to the supplier's installation instructions.

Product Name 0 0 0 0 0 0 0 0 .

Product Identity 0 0 0 0 0 0 0 0 .

Name of the installer 0 0 0 0 0 0 0 ...

The installer's signature 0 0 0 0 0 0 .

Installation company 0 0 0 0 0 0 0 ...

Date 0 0 0 0 0 0 0 0 0 0 0 0 .